

The most common causes of E4 printer problems:

1. Dirty, improperly calibrated or improperly positioned tape sensor: This can cause:

- A. Random skipping of labels
- B. Printing wanders on the label (**loss of correct alignment**)
- C. Printer errors (**ready and media lights flashing**)

2. Incorrect installation of the ink ribbon:

1. If the new ink ribbon is loaded with the **dull side of the ink ribbon facing in**. This causes the ink to come in direct contact with the printhead. This can cause:

- A. Poor print quality.
- B. The ink ribbon to stick to the printhead and burn holes in the ink ribbon.
- C. Buildup of burned ink on the printhead.

This will reduce the lifespan of the printhead, and cause permanent damage to the printhead.

2. If the **flat ends** of the ink ribbon spindles are **not installed toward the left side of the printer**. This can cause:

- A. The ink ribbon will not feed correctly, or will not feed at all.
- B. Slack in the ink ribbon.
- C. The ink ribbon to stick to the label tape during printing.
- D. The ink ribbon to stick to the printhead.
- E. Intermittent printer errors (**ready and ribbon lights flashing**)

3. If the ink ribbon is installed **without the rewind paper core** in place. This can cause:

- A. Intermittent printer errors (**ready and ribbon lights flashing**)
- B. Slack in the ink ribbon.
- C. The ink ribbon to stick to the label tape during printing.
- D. The ink ribbon will not rewind properly.
- E. The ink ribbon to stick to the printhead.

3. Incorrect switch settings:

The 8 switches on the back of the printer **must ALL be in the OFF position** for correct operation of the printer.

If any of the switches are turned on, it will cause unpredictable problems, such as:

- A. The labels will back up into the printer before printing.
- B. The printer will randomly skip labels.
- C. The printer will not calibrate properly.
- D. The print quality will be poor, or it may not print at all.
- E. The printer will not communicate correctly with the computer causing printer, and possible computer errors.

- F. A random combination of any of the above

If any of the switches need to be turned OFF:

1. Turn off the printer. **DO NOT** unplug any of the cables.
2. Turn off the switches by sliding them to the OFF position.
3. Restart the printer.
4. Re-calibrate the tape sensor.