

Easy Seal III AV

Diagnostic Procedure Manual

for the HS177

The step-by-step procedures in this manual will help a **service technician** or **qualified maintenance person** to quickly identify the cause of problems in the machine. The service technician or qualified maintenance person must have the ability to use a meter to take AC voltage, DC voltage and resistance readings at specific points in the machine.

TOOLS REQUIRED

To perform the tests in this manual, you will need a meter that will measure AC voltage, DC voltage, resistance (Ohms) and simple hand tools. Some of these test procedures require a second person to assist in performing the tests.

When performing any of the test procedures in this manual, **DO NOT** connect the machine to a power source until instructed to do so. When power is connect to the machine, use extreme caution when working on the machine.

******* CAUTION *******

Some of the test procedures in this manual require that the machine be plugged in and turned on.

USE CAUTION WHEN PERFORMING VOLTAGE TESTS.

Test Procedures in this Manual

Page 3.	Common Problems and Causes
Page 5.	Temperature Controller Error Codes
Page 5.	Temperature Setting Procedure
Page 6.	Air Leaks
Page 7.	Temperature Controller Reset Procedure
Page 11.	Temperature Controller Lockout Procedure
Page 12.	Touch Board Adjustment Procedure
Page 13.	Touch Board Sense Wire Test Procedure
Page 14.	Touch Board Bypass Wiring Procedure
Page 15.	Start Switch Test Procedure
Page 16.	Timer Test Procedure
Page 18.	Air Valve Test Procedure
Page 20.	Flow Control Adjustment Procedure
Page 22.	Muffler (Speed Control) Adjustment Procedure
Page 23.	Emergency Stop Switch Test Procedure
Page 24.	No Heat Test Procedure
Page 26.	Overheat Test Procedure
Page 28.	Heater and Wiring Test Procedure
Page 29.	Pressure Switch Adjustment Procedure
Page 30.	Pressure Switch Test Procedure
Page 31.	Machine Wiring Diagram

Common Problems and Causes

Head will not go down - The most common causes of this problem are:

1. Operator lockouts active

The machine is designed so it will not operate if:

A - The actual temperature reading of the heaters is 15 degrees above or below the temperature setting.

B - If the air pressure setting is below 42 PSI, (2.8 BAR).

- 2. The upper and lower heaters are not aligned**
- 3. The head is moving too fast from side to side**
- 4. The micro switch is faulty or out of adjustment**
- 5. Emergency stop button pressed**
- 6. Touch board faulty or out of adjustment**
- 7. Broken touch board sense wire**
- 8. Faulty timer**
- 9. Faulty valve**

Head will not stay down - The most common causes of this problem are:

- 1. Touch board faulty or out of adjustment**
- 2. Broken touch board sense wire**
- 3. Faulty timer**

Head will not come up - The most common causes of this problem are:

- 1. Faulty timer**
- 2. Faulty valve**

Head moves up / down too slow - The most common causes of this problem are:

- 1. Oil or water contamination**
- 2. Faulty or plugged muffler (speed control)**
- 3. Faulty or plugged valve**
- 4. Faulty air cylinder**

Head will not move left / right - The most common causes of this problem are:

1. **No air pressure to the machine**
2. **Air pressure set too low**
3. **Oil or water contamination**
4. **Faulty start button air valve**
5. **Incorrect flow control adjustment**
6. **Faulty flow control**
7. **Faulty or plugged valve**
8. **Faulty air cylinder**

Head moves left / right too slow - The most common causes of this problem are:

1. **Air pressure set too low**
2. **Incorrect flow control adjustment**
3. **Faulty flow control**
4. **Faulty or plugged valve**
5. **Faulty air cylinder**




Head moves left / right too fast - The most common causes of this problem are:

1. **Air pressure set too high**
2. **Incorrect flow control adjustment**
3. **Faulty flow control**





Heating problems (no heat & overheat) The most common causes of this problem are:


1. **Temperature setting too high or too low**
2. **Temperature controller set incorrectly**
3. **Faulty relay**
4. **Broken wiring to heater**
5. **Faulty temperature sensor**
6. **Faulty temperature controller**
7. **Faulty heater**

Temperature Controller Error Codes.

1. Temperature controller display reads: . This indicates a faulty thermocouple.
2. Temperature controller display reads: . This indicates a broken thermocouple.
3. Temperature controller display reads: . This indicates a faulty controller.

Temperature Controller Setting Procedure

1. Press . The display will read: . Press the  or  arrow buttons to change the setting.

Press  to save the change.

If the temperature setting will not change, the controller has been locked to prevent changes. To make changes, see the temperature controller lockout procedure for instructions to unlock the controller.

Air Leaks

Effects of Oil and Water in the Air Supply

The pneumatic components (valves and cylinders) used in the Easy Seal III AV heat seal machines have self-lubricating piston rings and cup seals that do not require any lubrication. Introduction of oil or water into the system degrades the seals in these components and causes premature wear and failure of the seals. Failure of these seals will cause air leaks and erratic operation.

Any leaking cylinders, valves, regulators and pressure switches should be repaired or replaced as soon as possible to ensure correct operation of the machine. Repair of the air leaks will require re-building or replacement of the leaking component.

Locating Air Leaks

General air leaks:

1. Turn the machine off and unplug it.
2. Remove the back cover.

If air is leaking around the shaft of the air cylinder, rebuild or replace the air cylinder.

(The 4" air cylinder in the HS177-1 can be rebuilt)

If air is leaking from the air pressure regulator, air pressure switch, air pressure gauge, push button valves, air valves or the air filter assembly, the leaking part will have to be replaced.

(The air valves in these machines cannot be rebuilt)





Air leaking from the muffler (speed control):



1. Turn the machine off and unplug it.
2. Disconnect the air line from the machine.
3. Remove the back cover.
4. Disconnect the air line connected to the top of the air cylinder.
5. Connect the air line to the machine.


If air is leaking from the fitting on the air cylinder, rebuild or replace the air cylinder.



If air is leaking from the air line, replace the air valve.





Temperature Controller Reset Procedure


1. Press . The display should read: . If it doesn't, press the  or  arrow

buttons until the display reads:  and press .

2. Press , hold it and press  The display will read: .




3. Press  until the display reads: .



4. Press  until the display reads: . Press the  or  arrow





buttons until the display reads: .

5. **Turn the machine OFF and allow it to cool down to room temperature.**

6. Turn the machine ON.

7. Press , hold it and press . The display will read: .

8. Press  until the display reads: .

9. Press . The display will read: . Press the  or  arrow

buttons until the display reads: .

10. Press . The display should read: . If it doesn't, press the arrow

button until the display reads: . (The JF will flash)

11. Press . The JF will stop flashing.

12. Press until the display reads: . If it doesn't, press the or arrow

buttons until the display reads: . (The BAND will flash)

13. Press . The BAND will stop flashing.

14. Press until the display reads: . If it doesn't, press the or arrow

buttons until the display reads: . (The 15 will flash)

15. Press . The 15 will stop flashing.

16. Press until the display reads: . Press the or arrow buttons until






the display reads: . (The ALA1 will flash)



Press . The ALA1 will stop flashing.


17. Press until the display reads: . If it doesn't, press the or arrow




buttons until the display reads: . (The PRI will flash)

18. Press . The PRI will stop flashing.


19. Press  until the display reads: 
. Press the  or  arrow buttons until





the display reads: 
. (the A2_r will flash)




Press . The A2_r will stop flashing.




20. Press  until the display reads: 
.





Turn OFF the machine, WAIT 5 seconds and turn the machine ON.






The **lower** display will read: .



21. Press , hold it and press  The display will read: 
.






22. Press  until the display reads: 
.



23. Press . The display will read: 
.





24. Press the  or  arrow buttons until the display reads: 
.


25. Press . until the display reads: 
. If it doesn't, press the  or  arrow





buttons until the display reads: 
.


26. Press . until the display reads: 
. If it doesn't, press the  or  arrow





buttons until the display reads: 
.


27. Press  until the display reads: . If it doesn't, press the  or  arrow

buttons until the display reads: .





28. Press  until the display reads: . If it doesn't, press the  or  arrow

buttons until the display reads: .


29. Press  until the display reads: . Press the  or  arrow

buttons until the display reads: .

Turn OFF the machine. Wait 5 seconds and turn on the machine.

30. Press . The display will read: . Press the  or  arrow

buttons to change the temperature to the required setting.

31. Press  to save the change.



Turn OFF the machine. Wait 5 seconds and turn on the machine.



(if the setup is correct, the “AT” light on the controller will be flashing)






Allow the machine to warm up to operating temp. This completes the controller setup. The machine is now ready to operate.



Temperature Controller Lockout Procedure






1. Turn the machine ON.


2. Press , hold it and press . The display will read: 

3. Press  until the display reads: 

4. Press . The display will read: . Press the  or  arrow buttons until the display reads: 

5. Press . The display should read: 

6. Press  until the display reads: . Press the  or  arrow buttons until the display reads: . (The 6 will flash)

7. Press . The 6 will stop flashing.


Turn OFF the machine. Wait 5 seconds and turn on the machine.

This prohibits the temperature setting from being changed. The controller will have to be unlocked to make any temperature setting changes.

To unlock the controller, follow the procedure above and change the setting in step 6 back to 1.

Touch Board Adjustment Procedure


1. Turn the machine off and unplug it.
2. Remove the back cover. The touch board is located inside of the case on the right side.
3. Remove the touch guard sensor wire from the sensor input connector.
4. Plug in the machine, turn it on and allow it to warm up.
5. Turn the sensor detect adjustment screw until the sensor detect light turns off.
6. Adjust the sensor detect adjustment screw until the sensor detect light turns back on.
7. Reconnect the touch guard sensor wire to the sensor input connector.
(If it is adjusted correctly, the sensor detect light will go out.)
8. Adjust the trigger adjustment until the trigger light turns on when you touch the bar with **one** finger.



9. If the touch board operates erratically, turn off the machine, unplug it and follow the instructions to test the touch sense wire.
10. If the touch board will not adjust or operate correctly, turn off the machine, unplug it and follow the instructions to bypass the touch board to test the machine.

Touch Board Sense Wire Test Procedure

1. Turn the machine off and unplug it.
2. Remove the back cover. The touch board is located inside of the case on the right side.



3. Remove the sensor wire from the touch board.
4. Set the meter to read OHMS and select the lowest OHMS scale on the meter.
5. Connect one of the meter leads to the sensor wire.
6. Connect the other meter lead to the touch bar.

If the wire is good, the meter will read ZERO OHMS.

If there is no reading on the meter, replace the sensor wire.

7. Keep the meter leads connected, disconnect the air pressure from the machine and allow the upper head to come down.


If the meter reading changes when the head is moving, replace the sensor wire.

Touch Board Bypass Wiring Procedure

USE FOR DIAGNOSTIC PURPOSES ONLY

DO NOT OPERATE MACHINE WITH THE TOUCH BOARD BYPASSED

1. Turn the machine off and unplug it.
2. Remove the back cover. The touch board is located inside of the case on the right side.
3. Disconnect the RED wire from the terminal block on the touch board.
4. Connect the RED wire to the same terminal as the black wire as shown.



7. Plug in the machine, turn it on and allow it to warm up.
8. Operate the machine.

If bypassing the touch board corrects the problem, turn off the machine, unplug it and replace the touch board.


DO NOT OPERATE MACHINE WITH THE TOUCH BOARD BYPASSED

Start Switch Test Procedure

***** CAUTION *****

THIS TEST PROCEDURE REQUIRES THAT THE MACHINE BE PLUGGED IN AND TURNED ON. USE CAUTION WHEN PERFORMING VOLTAGE TESTS.

1. Turn the machine off and unplug it.
2. Remove the back cover.
3. Set the meter to read AC voltage.
4. Inspect the microswitch. If it is damaged or the roller is bent, replace the microswitch.
5. Inspect the switch actuator pin. If the pin is loose or the bushing is missing, replace the switch actuator arm and the bushing.
6. Connect the black meter lead onto terminal # 2 on the terminal block.
(terminal # 2 on the terminal block has all of the white wires connected to it.)
7. Connect air pressure to the machine.
8. Connect the red meter lead to terminal # 7 on the timer socket. The meter should read 0 volts AC.
9. Plug in the machine, turn it on and allow it to warm up to operating temperature.



View from the back of the machine

CAUTION:

**THE HEAD MAY OPERATE DURING THIS TEST.
KEEP HANDS AWAY FROM ALL MOVING PARTS**

10. Manually, press down the roller on the microswitch. When the roller is pressed, the voltage on terminal # 7 should read 110 volts AC.

If not, check these items:

- A: Temperature controllers (not ready)
- B: Pressure switch (set too low or no pressure)
- C: Touch board (not adjusted correctly or faulty)
- D: Emergency stop switch (button pressed in)


If items A, B, C, D are correct, replace the microswitch.

Timer Test Procedure

***** CAUTION *****

THIS TEST PROCEDURE REQUIRES THAT THE MACHINE BE PLUGGED IN AND TURNED ON. USE CAUTION WHEN PERFORMING VOLTAGE TESTS.

1. Turn the machine off and unplug it.
2. Remove the back cover.
3. Set your meter to read AC voltage.
4. Connect the black meter lead onto terminal # 2 on the terminal block.
(terminal # 2 on the terminal block has all of the white wires connected to it.)
5. Connect air pressure to the machine.
6. Plug in the machine, turn it on and allow it to warm up to operating temperature.



View from the back of the machine

7. Connect the red meter lead to terminal # 1 on the timer socket. The display should read 110 volts AC.

If not, check these items:

- A: Touch board (setup)
- B: Emergency stop (button pressed)

8. Remove the red meter lead from terminal # 1 and connect it to terminal # 4 on the timer socket. The display should read 110 volts AC.

If not, replace the timer.

9. Remove the red meter lead from terminal # 4 and connect it to terminal # 7 on the timer socket. The display should read 0 volts AC.

10. Press the start button under the case. When the start button is pressed, the voltage on terminal # 7 should read 110 volts AC.

CAUTION:

**THE HEAD MAY OPERATE DURING THIS TEST.
KEEP HANDS AWAY FROM ALL MOVING PARTS**

If not, check these items:

- A: Temperature controllers (not ready)
- B: Pressure switch (set too low or no pressure)

11. Press the black start button located near the center of the machine. When the start button is pressed, the head will move to the other side and will come down.

CAUTION:

**THE HEAD WILL MOVE AND THE MACHINE MAY OPERATE DURING THIS TEST.
KEEP HANDS AWAY FROM ALL MOVING PARTS**

When the head moves over the lower heater, the voltage on terminal # 7 should read 110 volts AC.

If not, check these items:

- A: Temperature controllers (not ready)
- B: Pressure switch (set too low or no pressure)
- C: Microswitch (out of adjustment)
- D: Microswitch (faulty)
- E: Timer (faulty)

12. Remove the red meter lead from terminal # 7 and connect it to terminal # 3 on the timer socket. The display should read 0 volts AC.

Press the black start button located towards the center of the machine. When the start button is pressed, the head will move to the other side and will come down.

CAUTION:

**THE HEAD WILL MOVE AND THE MACHINE MAY OPERATE DURING THIS TEST.
KEEP HANDS AWAY FROM ALL MOVING PARTS**

When the head moves over the lower heater, the voltage on terminal # 3 should read 110 volts AC.

If not, replace the timer.

Air Valve Test Procedure


***** CAUTION *****

THIS TEST PROCEDURE REQUIRES THAT THE MACHINE BE PLUGGED IN AND TURNED ON. USE CAUTION WHEN PERFORMING VOLTAGE TESTS.

1. Turn the machine off and unplug it.
2. Remove the back cover.
3. Set your meter to read AC voltage.
4. Connect the black meter lead onto terminal # 2 on the terminal block.
(terminal # 2 on the terminal block has all of the white wires connected to it.)
5. Connect air pressure to the machine.

If there is air leaking from the air valve, replace the valve.

6. Plug in the machine, turn it on and allow it to warm up to operating temperature.



View from the back of the machine

7. Connect the red meter lead to terminal # 1 on the timer socket. The display should read 110 volts AC.

If not, check these items:

- A: Touch board (setup)
- B: Emergency stop (button pressed)

8. Remove the red meter lead from terminal # 1 and connect it to terminal # 3 on the timer socket. The display should read 0 volts AC.
9. Press the start button under the case. When the start button is pressed, the voltage on terminal # 3 should read 110 volts AC.


CAUTION:

**THE HEAD MAY OPERATE DURING THIS TEST.
KEEP HANDS AWAY FROM ALL MOVING PARTS**

If not and the air valve does not operate, replace the valve.

Flow Control Adjustment Procedure

1. Turn the machine off and unplug it.
2. Remove the back cover.



3. Turn the adjustment screw on the flow controls to adjust the speed of the head from side to side.

Looking from the back of the machine:

A: The flow control on the **LEFT** side controls the speed of the head from **LEFT to RIGHT**.

B: The flow control on the **RIGHT** side controls the speed of the head from **RIGHT to LEFT**.


Clockwise - Decreases the speed of the machine.

Counter-clockwise - Increases the speed of the machine.

When adjusted correctly, the head will move at the same speed from side to side without bouncing or sliding on the table.

Muffler (Speed Control) Adjustment Procedure

Side view of the muffler



1. Loosen the locknut.
2. Turn the adjustment screw to change the speed of the machine.

Clockwise - Decreases the speed of the machine.

Counter-clockwise - Increases the speed of the machine.

3. When the desired speed is reached, tighten the locknut.
4. If the **speed does not change**, remove the muffler from the machine and test the machine. The machine should operate fast.

If it **does not operate fast**, check the air valve and the air cylinder for water and or oil contamination. If there is water or oil contamination, replace the valve and the air cylinder.

If it **does operate fast**, replace the muffler.

Emergency Stop Switch Test Procedure

***** CAUTION *****

THIS TEST PROCEDURE REQUIRES THAT THE MACHINE BE PLUGGED IN AND TURNED ON. USE CAUTION WHEN PERFORMING VOLTAGE TESTS.

1. Turn the machine off and unplug it.
2. Turning the emergency stop button in the direction of the arrows until it pops out.
3. Remove the back cover.
4. Set your meter to read AC voltage.
5. Connect the black meter lead onto terminal # 2 on the terminal block.
(terminal # 2 on the terminal block has all of the white wires connected to it.)
6. Plug in the machine and turn it on.
7. Connect the red meter lead to terminal # 3 on the terminal block.
(terminal # 3 on the terminal block has all of the red wires connected to it.)

The display should read 110 volts AC.

If not, turn the machine off and unplug it.

8. Disconnect the red meter lead from terminal # 3 on the terminal block and connect the red meter lead onto the red wire on the touch control board.
9. Plug in the machine and turn it on. The display should read 110 volts AC.

If the display reads 110 volts AC, turn the machine off, unplug it and replace the emergency stop switch.

If the displays **does not** read 110 volts AC, turn the machine off, unplug it and follow the instructions to re-adjust the touch board.

No Heat Test Procedure

***** CAUTION *****

THIS TEST PROCEDURE REQUIRES THAT THE MACHINE BE PLUGGED IN AND TURNED ON. USE CAUTION WHEN PERFORMING VOLTAGE TESTS.


1. Perform the temperature controller reset procedure.

If this does not correct the problem, turn the machine off and unplug it.

2. Swap the upper and lower controllers. (**DO NOT** disconnect the wiring from the controllers)

To remove the controller, pull the controller out of the housing as shown.

(Side View of Machine)




To install the controller, push the controller into the housing.

3. Plug in the machine and turn it on and allow it to warm up.

If the other heater stops heating, turn the machine off, unplug it and replace the temperature controller.

4. If the same heater still doesn't heat, turn the machine off and unplug it.
5. Remove the back cover.
6. Set your meter to read DC voltage.

7. Connect the black meter lead onto the terminal marked **4/A2-** on the relay.
8. Connect the red meter lead onto the terminal marked **+3/A1** on the relay.



9. Plug in the machine and turn it on. After approx 10 seconds, the green light on the relay should turn on and the display should read 12 volts DC.

If not, turn the machine off and unplug it. The problem is a faulty temperature sensor, faulty temperature controller or a broken wire from the temperature controller to the relay.

10. Turn the machine off and unplug it. Disconnect the meter leads from the relay.
11. Set the meter to read AC voltage. Connect the black meter lead onto terminal # 2 on the terminal block. (Terminal # 2 on the terminal block has all of the white wires connected to it.)
12. Connect the red meter lead to the terminal marked **1/L1** on the relay.

13. Plug in the machine and turn it on. The display should read 110 volts AC.

If not, turn the machine off and unplug it. The problem is a broken connection from the terminal block to the relay.

14. Turn the machine off and unplug it. Disconnect the red meter lead from the terminal marked **1/L1** on the relay.
15. Connect the red meter lead to the terminal marked **2/T1** on the relay.
16. Plug in the machine, turn it on. After approx 10 seconds, the display should read 110 volts AC.

If not, turn the machine off, unplug it and replace the relay.

If so, turn the machine off and unplug it. The problem is a break in the heater wiring or a faulty heater.

Overheating Test Procedure

***** CAUTION *****

THIS TEST PROCEDURE REQUIRES THAT THE MACHINE BE PLUGGED IN AND TURNED ON. USE CAUTION WHEN PERFORMING VOLTAGE TESTS.


1. Check that the temperature setting is correct.
2. Perform the temperature controller reset procedure.

If this does not correct the problem, turn the machine off and unplug it.

3. Swap the upper and lower controllers. (**DO NOT** disconnect the wiring from the controllers.)

To remove the controller, pull the controller out of the housing as shown.

(Side View of Machine)




To install the controller, push the controller into the housing.

4. Plug in the machine and turn it on and allow it to warm up to operating temperature.

If the other heater overheats, turn the machine off, unplug it and replace the temperature controller.

5. If the same heater still overheats, turn the machine off and unplug it.
6. Remove the back cover.
7. Set the meter to read DC voltage.
8. Connect the black meter lead onto the terminal marked **4/A2-** on the relay.

9. Connect the red meter lead onto the terminal marked **+3/A1** on the relay.




10. Plug in the machine and turn it on and allow it to warm up to operating temperature. The display should read 12 volts DC.
11. When the temperature of the heater is within 30 degrees of the set temperature, the 12 volts DC will begin to pulse on and off from 12 volts DC and 0 volts DC. This indicates that the controller is regulating the temperature of the heater

If the voltage on the meter reads 12 volts DC, and the temperature continues to rise above the temperature setting, turn off the machine off and unplug it. The problem is a faulty temperature sensor or a faulty temperature controller.

If the voltage on the meter changes to 0 volts DC and the temperature continues to rise, turn the machine off, unplug it and replace the relay.

Heater And Wiring Test Procedure

1. Turn the machine off and unplug it.
2. Remove the back cover.
3. Set your meter to read OHMS and select the lowest OHMS scale on the meter.
4. Connect the black meter lead onto terminal # 2 on the terminal block.
(terminal # 2 on the terminal block has all of the white wires connected to it.)
5. Disconnect the black wire from the terminal marked **2/T1** on the relay.
6. Connect the red meter lead to the wire that was connected to the terminal marked **2/T1** on the relay.




7. The resistance reading varies with the size of the heater.

The correct reading for the HS177-1 should be between 25 - 35 Ohms.

The correct reading for the HS177-5 should be between 40 - 50 Ohms.
8. If there is no resistance reading, the heater wiring is broken or the heater is faulty
9. If the resistance reading of the heater is higher or lower than listed, replace the heater.

Pressure switch adjustment procedure


1. Turn the machine off and unplug it.
2. Remove the back cover.
3. Turn the adjustment screw on the pressure switch until the top edge of the adjustment screw indicated the desired pressure.



4. Plug in the machine and turn it on. Test that the machine will not operate if the air pressure reading on the gauge falls below the setting on the pressure switch.

Pressure Switch Test Procedure

1. Turn the machine off and unplug it.
2. Disconnect the air line from the machine.
3. Remove the back cover.
4. Set your meter to read OHMS and select the lowest OHMS scale on the meter.
5. Disconnect the wires from the pressure switch.
6. Connect the black meter lead onto the terminal **COM** on the pressure switch.
7. Connect the red meter lead onto the terminal **NO** on the pressure switch.



8. There should be no reading on your meter.

If there is a reading, replace the pressure switch.

9. Keep the meter leads connected and connect the air pressure to the machine.

If the pressure switch is good, the display will read ZERO OHMS.

10. If there is no reading on your meter, check that the pressure setting on the air gauge is above the pressure setting on the pressure switch.

If the pressure settings are correct and there is no reading on your meter, replace the pressure switch.

HS177 Wiring Diagram

